

STIHL

STIHL TS 410, 420

Instruction Manual



Contents

Guide to Using this Manual	2
Safety Precautions and Working Techniques	2
Sample Applications	11
Cutting Wheels	14
Composite Abrasive Wheels	14
Diamond Abrasive Wheels	15
Electronic Water Control	18
Assembling the cast arm and guard	19
Tensioning the ribbed V-belt	23
Mounting an Abrasive Wheel	23
Fuel	25
Fueling	26
Starting / Stopping the Engine	27
Air Filter System	29
Adjusting the Carburetor	30
Spark Plug	32
Replacing the V-belt	33
Cut-off Machine Cart	34
Storing the Machine	34
Maintenance and Care	35
Minimize Wear and Avoid Damage	37
Main Parts	38
Specifications	39
Maintenance and Repairs	40
Disposal	41
EC Declaration of Conformity	41

Digital Instruction Manual

Printed on chlorine-free paper
Printing inks contain vegetable oils, paper can be recycled.

© ANDREAS STIHL AG & CO., KG, 2019
0458-370-0121-F, VBG/G19,
0000000891_023_GB

STIHL

TS 410, TS 420

This instruction manual is protected by copyright. All rights reserved, especially the rights to reproduce, translate and process with electronic systems.

Guide to Using this Manual

Symbols in text

⚠ WARNING

Warning where there is a risk of an accident or personal injury or serious damage to property.




Depending on the machine and equipment version, the following pictograms may appear on the machine.


Fuel tank; fuel mixture of gasoline and engine oil



Actuate decompression valve



Actuate manual fuel pump



STIHL's philosophy is to continually improve all of its products. For this reason we may modify the design, engineering and appearance of our products periodically.

Therefore, some changes, modifications and improvements may not be covered in this manual.


Water connection, shut-off cock



Tensioning nut for belt




Pull starter grip



Safety Precautions and Working Techniques

Special safety precautions must be taken when working with the cut-off machine, due to the very high rotational speed of the abrasive wheel.



It is important you read and understand the Instruction Manual before first use and keep the manual in a safe place for future reference. Non-observance of the safety instructions may result in serious or even fatal injury.



Comply with national safety regulations, e.g. issued by employers' liability insurance associations, social security institutions, occupational safety and health authorities or other organizations.

For employers within the European Union, Directive 2009/104/EC is binding
– Minimum safety and health requirements for the use of work equipment by workers at work.

Anyone using the power tool for the first time: Let the retailer or another expert explain to you how to handle it safely – or attend a training course.

Minors are not allowed to use the power tool, except adolescents above 16 years of age receiving instruction under supervision.

Keep children, animals and bystanders at a safe distance.

When the machine is not in use, put it down safely so that it does not endanger anyone. The machine must be secured against unauthorized access.

The user is responsible for accidents or hazards to third parties or damage to their property.

Hand over or lend the power tool only to persons who are familiar with this model and its handling – always give them the instruction manual as well.

The use of noise-emitting machines may be restricted to certain times by national or local regulations.

The machine may only be operated by people who are fit, in good physical health and in good mental condition.

If you have any condition that might be aggravated by strenuous work, check with your doctor before operating a power tool.

If you have a pacemaker: The ignition system of this machine produces an electromagnetic field of very low intensity. An effect on individual pacemaker types cannot be excluded entirely. STIHL recommends that you consult your doctor and the manufacturer of your pacemaker in order to avoid health hazards.

Never work with the machine while under the influence of alcohol, medication or drugs capable of impairing your reaction speed.

Postpone the work if the weather is bad (snow, ice, wind) – **higher risk of accidents!**

The machine is designed only for cutting as specified. It is not suitable for cutting wood or wooden objects.

Asbestos dust is extremely toxic – the machine must therefore **never be used to cut asbestos!**

Do not use the machine for any other purpose because of the increased risk of accidents and damage to the machine.

Do not modify the machine – otherwise safety may be compromised. STIHL excludes all liability for personal injury and damage to property caused by using unauthorized attachments.

Only use abrasive wheels or accessories which have been approved by STIHL for this machine or which are technically equivalent. If you have any questions in this respect, consult a servicing dealer. Only use high-quality abrasive wheels and attachments.

Otherwise there may be a risk of accidents or damage to the machine.

STIHL recommends the use of genuine STIHL abrasive wheels and accessories. These have been optimized for the product and the user's requirements.

Do not use a pressure washer to clean the machine. The strong water jet can damage parts of the machine.

Do not spray the machine with water.

Never work with the machine while under the influence of alcohol, medication or drugs capable of impairing your reaction speed.

Postpone the work if the weather is bad (snow, ice, wind) – **higher risk of accidents!**


The machine is designed only for cutting as specified. It is not suitable for cutting wood or wooden objects.

Never use circular saw blades, carbide, rescue or wood cutting attachments or saws of any kind – **these may cause fatal injuries!** Instead of uniformly removing particles as when cutting with an abrasive wheel, the teeth of a circular saw blade may snag in the material. This causes the machine to react in a highly aggressive manner with uncontrolled and extremely dangerous kickback.



Clothing and equipment

Wear proper protective clothing and equipment.



Clothing must be sturdy and snug-fitting, but allow complete freedom of movement. Wear close-fitting clothes such as a boiler suit, not a loose jacket

When cutting steel, always wear clothing made of barely flammable material (e.g., leather or cotton with flame-retardant finish) – no man-made fibers – **risk of fire due to flying sparks!**

Ensure that there are no flammable deposits (chips, fuel, oil, etc.) on your clothing.

Remove any clothes that could be trapped by moving parts, such as a scarf, tie or jewelry. Long hair must be tied up and covered.

Wear safety boots with steel toe caps and non-slip soles.



! WARNING
To reduce the risk of eye injuries, wear tight-fitting safety goggles conforming to standard EN 166.
Make sure that the safety goggles fit correctly.



Wear a face mask and make sure it fits correctly. A face mask alone is not sufficient to protect the eyes.

Wear a hard hat wherever there is any risk of falling objects.

While working, dust (for example, crystalline material from the object to be cut), vapor and smoke may be produced – **danger to health!**

Always wear a **dust mask** if dust is generated.

If fumes or smoke are anticipated (e.g., when cutting composite materials), wear **respiratory protection**.

Wear "personal" **hearing protection** – for example, ear defenders.

Wear sturdy protective gloves made of a resistant material (e.g., leather).



STIHL can supply a comprehensive range of personal protective clothing and equipment.

Transporting the machine

Dust may collect on the engine unit, especially around the carburetor. If dust gets mixed with fuel – risk of fire!
Remove the dust from the engine unit regularly.

Look out for leaks! Never start the engine if fuel has been spilled or is leaking
- **Fatal burns may result!**



Never transport the power tool with cutting wheel fitted – **risk of breakage!**

In vehicles: Properly secure the machine to prevent turnover, damage and fuel spillage.

Refueling

Gasoline is an extremely flammable fuel – keep clear of naked flames and fire – do not spill any fuel – no smoking.




Switch off the engine before refueling.

Never refuel the machine while the engine is still hot – the fuel may spill over – **risk of fire!**

Open the fuel filler cap carefully so that any excess pressure is relieved gradually and fuel does not splash out.


The machine may only be refueled in a well ventilated place. If fuel has been spilled, immediately clean the machine – do not allow your clothes to be splashed with fuel. If that happens, change your clothes at once.

Bayonet filler cap



Different cut-off machines may be equipped with different filler caps:
Bayonet filler cap

Filler cap with screw thread



Close the filler cap as tightly as possible after refueling.
This helps reduce the risk of engine vibrations causing an incorrectly tightened filler cap to loosen or come off and spill quantities of fuel.

Cut-off machine, spindle bearing

Correct spindle bearings ensure the concentricity and axial running of the diamond-tipped abrasive wheel – if necessary, get it checked by an approved dealer.

Abrasive wheels

The permissible speed of the abrasive wheel must be equal to or greater than the maximum spindle speed of the cut-off machine. – Refer to the chapter "Specifications".

Selecting the abrasive wheels
Abrasive wheels must be approved for hand-held cutting. Do not use other cutting wheels and attachments – **risk of accident!**


Before fitting a used abrasive wheel, check that it is not cracked, chipped, undercut or uneven, and does not display any signs of core fatigue or overheating (discoloration); check also that there are no damaged or missing segments and that the spindle hole is not damaged.

Never use cracked, chipped or bent abrasive wheels.

Abrasive wheels are suitable for different materials: Observe the identification of the abrasive wheels.

STIHL generally recommends wet cutting.

Observe the outer diameter of the abrasive wheel.



Spindle hole diameter of the abrasive wheel and shaft of cut-off machine must match.

Check the spindle hole for damage. Do not use cutting wheels with a damaged spindle hole – **risk of accident!**

Fitting abrasive wheels

Inspect the spindle of the cut-off machine. Do not use a machine if the spindle is damaged – **risk of accident!**

Note the arrows indicating the direction of rotation on diamond abrasive wheels.
Position the front pressure plate – tighten up the clamping screw – rotate the cutting wheel by hand and take a sight check for concentricity and axial running.

Storing abrasive wheels

Store cutting wheels in a dry and frost-free place, on an even surface, at constant temperature – **risk of breakage and splintering!**

Always protect the abrasive wheel against sudden contact with the ground or objects.

Before starting

Inspect the cut-off machine to check that it is in full working order – observe the respective chapters in the instruction manual:

- Check the fuel system for leaks, especially the visible parts, e.g., filter cap, hose connections, manual fuel pump (only on machines with a manual fuel pump). In case of leakage and damage, do not start the engine – **risk of fire!** Have the machine serviced by a servicing dealer before using it.

- The abrasive wheel must be suitable for the material to be cut. It must be in good condition and fitted correctly (direction of rotation, secure).

- Inspect the cutting wheel guard for tight seat – if loose, contact your specialist dealer.

English

- Both the throttle trigger and the throttle trigger lockout must move smoothly – the throttle trigger must automatically return to the idle position.
- Slide control / master control / stop switch must move easily to **STOP or 0**
- Check that the spark plug boot is secure. A loose boot can lead to flying sparks which may ignite the escaping fuel/air mixture – **risk of fire!**
- Never attempt to modify the controls or safety devices in any way
- Keep the handles clean, dry, and free of oil and dirt – important for good control of the cut-off machine.
- For wet applications, provide sufficient water

The machine should only be used if it is in good working order – **risk of accident!**

Starting the engine

Move at least 3 meters away from the place at which the machine was refuelled and never start the machine in an enclosed space.

On even ground, ensure a firm and secure footing and hold the power tool firmly – the cutting wheel must not touch the ground or any objects and must not be in the cut.

The abrasive wheel may begin to rotate as soon as the machine is started.

The machine is operated by a single person only – do not allow anyone else within the working area – not even when starting.

Do not drop-start the engine – start as described in the Instruction Manual.

After releasing the throttle trigger, the abrasive wheel keeps on running for a while – **danger of injury due to coasting effect!**

Holding and controlling the machine

- Keep the handles clean, dry, and free of oil and dirt – important for good control of the cut-off machine.
- For wet applications, provide sufficient water


The machine should only be used if it is in good working order – **risk of accident!**

Starting the engine

Move at least 3 meters away from the place at which the machine was refuelled and never start the machine in an enclosed space.

On even ground, ensure a firm and secure footing and hold the power tool firmly – the cutting wheel must not touch the ground or any objects and must not be in the cut.

The abrasive wheel may begin to rotate as soon as the machine is started.



When a cut-off machine with an abrasive wheel rotating is moved in the direction of the arrow, a force is produced which causes the machine to tip sideways.

The object to be cut has to be firmly supported. Always guide the machine towards the workpiece, never the other way round.

Cut-off machine cart

STIHL cut-off machines can be mounted on a STIHL cut-off machine cart.


Guard

The adjustment range of the guard is determined by a stop pin. Never push the guard over the stop pin.



Set the abrasive wheel guard correctly:
Direct particles of material away from the user and machine.

Note the direction of travel of the abraded particles of material.



The cut-off machine may only be used for hand-held cutting or when mounted on a STIHL cut-off machine cart.

Hand-held cutting

Always hold the machine **firmly with both hands**: Right hand on the rear handle – even if you are left-handed. To ensure reliable control, wrap your thumbs tightly around the handlebar and handle.

002BA549 AM

During operation	<p>Work calmly and carefully – in daylight conditions and only when visibility is good. Work with particular care, do not endanger others.</p> <p>If there is imminent danger or in an emergency, immediately stop the engine – set the slide control / master lever /stop switch to STOP or 0.</p> <p>Check for correct idling so that the abrasive wheel is no longer driven when the throttle trigger is released and comes to a complete halt.</p> <p>Check and/or correct the idle setting regularly. Have the machine repaired by a STIHL servicing dealer if the cutting wheel continues to turn nevertheless.</p> <p>Keep the working area clear – bear in mind obstacles, holes and pits.</p> <p>Take care on ice, water, snow, on slopes or uneven ground, etc. – risk of slipping!</p> <p>Do not work while standing on a ladder – or in unstable places – not above your shoulder height – not with one hand only – risk of accident!</p> <p>Ensure you always have a firm and secure footing.</p> <p>Never work alone – always stay in earshot of other persons who can help in an emergency.</p> <p>Keep everyone else away from the working area – maintain a sufficient distance from other people to protect them from noise and flying objects.</p> <p>Pay increased attention and take greater care when wearing ear defenders – the perception of sounds indicating potential danger (shouts, audible warnings, etc.) is restricted.</p> <p>Take a break before it is too late.</p>	
		operating a machine which is damaged. In case of doubt, have the unit checked by your servicing dealer.
		Do not work with the throttle trigger in the starting throttle position – in that position of the throttle trigger, the engine speed cannot be controlled.
		Never touch a rotating abrasive wheel with your hand or any other part of your body.
		Check the work area. Avoid danger due to damage to pipes and electric power lines.
		The machine must not be used in the vicinity of flammable substances and combustible gases.
		Do not cut into pipes, metal tanks or other containers unless you are absolutely sure that they do not contain any volatile or flammable substances.
		Never leave the machine unattended with the engine running. Stop the engine before leaving the machine unattended (e.g. for breaks).
		Before putting the cut-off machine down on the ground:
		– Switch off the engine
		– Wait until the abrasive wheel has come to a standstill or brake the abrasive wheel until it comes to a standstill by carefully touching a hard surface (e.g., concrete slab)
		No smoking when working with or near the machine - risk of fire!
		If the power tool has been exposed to stress due to improper use (e.g. forceful impact by striking or dropping), inspect the machine to make sure it is in full working order before continuing work, in every case – see also "Before start-up". Check the fuel system for leaks and make sure the safety devices are working properly. Do not continue





Frequently inspect the cutting wheel – replace the wheel right away if there are visible cracks, buckling or other damage (for example, overheating) – **risk of accident due to breakage!**

In the event of changes in cutting behavior (e.g., increased vibration, reduced cutting performance), stop work and eliminate the causes of the changes.

Reactive forces

The most frequently occurring reactive forces are kickback and pull-in.

Danger of kickback – **Kickback can result in fatal injuries.**




Kickback occurs if, for example, the abrasive wheel

- gets jammed – especially the upper quarter, or
- is abruptly braked through friction contact with a solid object

Reducing the risk of kickback

- Work cautiously and methodically
- Hold the cut-off machine firmly with both hands and maintain a secure grip




- Avoid any wedge effect - the severed part must not brake the abrasive wheel


- Always be aware that the object to be cut may move and other factors may cause the cut to close and jam the abrasive wheel.

- The object to be cut must be secured and supported so that the kerf remains open during and after cutting

- Objects to be cut must therefore be fully supported and must be secured against rolling away, slipping off or vibrations



Kickback occurs when the cut-off machine is suddenly thrown up and back in an uncontrolled arc towards the operator.




- 002BA555 AM

- 002BA552 AM


- 002BA551 AM

Working – cutting



- An exposed pipe must be provided with a stable support that will bear its weight, using wedges if necessary – always bear in mind a proper support and the nature of the ground – material may crumble away
- Always work with water and wet cutting when using diamond abrasive wheels
- Depending on the version, resin abrasive wheels are only suitable for dry cutting or only for wet cutting. Always use wet cutting with composite resin abrasive wheels that are suitable only for wet cutting

Pulling away




The cut-off machine pulls forwards, away from the user, when the abrasive wheel touches the object to be cut from above.

- Always decide the cutting direction before positioning the cut-off machine.
- Do not change the cutting direction.
- Never use the machine to push or hit into the cutting gap – do not let the machine fall into the gap – **risk of breakage!**

Diamond abrasive wheels: If cutting performance begins to deteriorate, check the sharpness of the diamond cutting wheel, resharpen as needed. To do this, briefly cut through abrasive material, e.g., sandstone, aerated concrete or asphalt.

At the end of the cut, the cut-off machine is no longer supported in the cut by the abrasive wheel. The user has to absorb the weight force – **risk of loss of control!**

When cutting steel: glowing metal particles **may cause fires!**



Keep water and sludge away from live electrical cables – **risk of electric shock!**

Pull the cutting wheel into the workpiece – do not push it into the material. Do not use the cut-off machine to correct severing cuts. Do not re-cut – remove any webs or breaking edges manually (for example, with a hammer).

When using diamond-coated cutting wheels, make a wet cut – for example, use the STIHL water connector. Depending on the version, resin abrasive wheels are only suitable for dry cutting or only for wet cutting.

Do not press down on the cut-off machine.

English

<p>When using cutting wheels made from synthetic resin which are suitable for wet cuts only, make wet cuts only – for example, use the STIHL water connector.</p>	<p>The period of usage is shortened by:</p> <ul style="list-style-type: none">– Any personal tendency to suffer from poor circulation (symptoms: frequently cold fingers, tingling sensations).– Low outside temperatures.– The force with which the handles are held (a tight grip restricts circulation).	<p>injury if the engine starts up inadvertently! – Exception: adjustment of carburetor and idle speed.</p> <p>To reduce the risk of fire due to ignition outside the cylinder, move the slide control / stop switch to STOP or 0 before turning the engine over on the starter with the spark plug boot removed or the spark plug unscrewed.</p> <p>Do not service or store the machine near a naked flame – risk of fire due to the fuel.</p>
<p>When using abrasive wheels made from synthetic resin, which are suitable for dry cuts only, make dry cuts only. If composite resin abrasive wheels of this type become wet, their cutting performance is reduced and they become dull. If composite resin abrasive wheels of this type become wet while working (e.g., due to puddles or water in pipes), do not increase the cutting pressure, but continue working with the same pressure – risk of breakage! Use up such composite resin abrasive wheels immediately.</p>	<ul style="list-style-type: none">– The force with which the handles are held (a tight grip restricts circulation). <p>Continual and regular users should monitor closely the condition of their hands and fingers. If any of the above symptoms appear (e.g. tingling sensation in fingers), seek medical advice.</p>	<p>Check fuel cap regularly for tightness.</p> <p>Use only spark plugs that are in perfect condition and have been approved by STIHL – see Specifications.</p> <p>Inspect ignition lead (insulation in good condition, secure connection).</p>
<p>Cut-off machine cart</p> <p>Clear a path for the cut-off machine cart. If the cart is pushed over objects, the abrasive wheel may become wedged in the cut and shatter!</p>	<p>The machine must be serviced regularly. Do not attempt any maintenance or repair work not described in the Instruction Manual. All other work should be carried out by a servicing dealer.</p>	<p>Check that the muffler is in perfect working condition.</p> <p>Do not use the machine if the muffler is damaged or missing - risk of fire! – Hearing damage!</p> <p>Never touch a hot muffler – risk of burns!</p> <p>Check the rubber buffers underneath the machine - the housing must not rub against the ground - risk of damage!</p> <p>The condition of the antivibration elements influences vibration behavior – inspect antivibration elements periodically.</p>
<p>Vibrations</p>	<p>Prolonged use of the power tool may result in vibration-induced circulation problems in the hands (whitefinger disease).</p> <p>No general recommendation can be given for the length of usage because it depends on several factors.</p> <p>The period of usage is prolonged by:</p> <ul style="list-style-type: none">– Hand protection (wearing warm gloves)– Work breaks	<p>STIHL recommends that maintenance and repair work be carried out only by authorized STIHL dealers. STIHL dealers receive regular training and are supplied with technical information.</p> <p>Use only high-quality replacement parts, in order to avoid the risk of accidents or damage to the machine. Contact a dealer if in doubt.</p> <p>STIHL recommends the use of genuine STIHL spare parts. Such parts have been optimized for the machine and the user's requirements.</p> <p>Before starting any maintenance or repair work and before cleaning the machine, always stop the engine and disconnect the spark plug boot – risk of</p>

Sample Applications

If fumes or smoke are anticipated (e. g., when cutting composite materials), wear **respiratory protection**.

Water must always be used for wet cutting when working with diamond abrasive wheels



Composite resin abrasive wheels suitable only for wet cutting

Use abrasive wheel only with water.

Severed parts


With openings, recesses, etc., the sequence of the cuts is important. Always make the last cut so that the abrasive wheel does not become jammed and so that the operator is not endangered by the severed or separated part.

If necessary, leave small ridges that hold the part that is to be separated in position. Break these ridges later.

Before finally separating the part, determine:

- how heavy the part is
 - how it can move after separation
 - whether it is under tension
- When breaking out the part, do not endanger assistants.

Cut in several passes



- Mark cutting line (A)

Extend service life and increase cutting speed

Always ensure a supply of water to the abrasive wheel.

Binding dust

The abrasive wheel must be supplied with at least 0.6 liters of water per minute.

Water attachment

- Water attachment on the machine for all types of water supplies
- Pressurized water tank 10 l for binding dust
- water tank usable on the cut-off machine cart for binding dust

Use composite resin abrasive wheels with or without water – depending on version

Observe with diamond and composite resin abrasive wheels


Depending on the version, resin abrasive wheels are only suitable for dry cutting or only for wet cutting.

Composite resin abrasive wheels suitable only for dry cutting

During dry cutting, wear a suitable dust mask.

Objects to be cut


- Must be fully supported
- Must be secured so it cannot roll or slip off
- Must be prevented from vibrating




- Work along the cutting line. When making corrections, do not tilt the abrasive wheel, but always set the abrasive wheel against the workpiece anew – the cutting depth for each operation should not exceed 5 to 6 cm. Cut thicker material in multiple operations

Cutting plates

- Secure the plate (e. g. on a non-slip surface, sandbed)




- Grind a guide groove (A) along the line marked



- Make the cut (B) deeper
- Leave a "hinge" (C)
- First sever the plate at the cut ends so that no material breaks away
- Break plate


Cutting concrete pipe




The procedure is dependent on the outer diameter of the pipe and the maximum possible cutting depth of the abrasive wheel (A).

Cutting pipes, round and hollow bodies

- Secure pipes, round and hollow bodies against vibrations, slipping and rolling away
- Note direction of fall and weight of the severed part
- Determine and mark the cutting line, avoid reinforcement, especially in the direction of the severing cut
- Determine sequence of severing cuts
- Secure pipe against vibrations, slipping and rolling away
- Note weight, tension and direction of fall of the part to be severed




- Second lateral cut in the marked area – never cut into the area of the last cut, to ensure a firm hold on the part of pipe to be cut
- Only make the last top cut once all bottom and lateral cuts have been made.




- Last cut always from the top (approx. 15 % of the pipe circumference)

Concrete pipe – cut recess


- Sequence of cuts (1 to 4) is important:
- First, cut hard-to-reach areas




- Always start at the bottom, use the upper quarter of the abrasive wheel for cutting




- Use the upper quarter of the abrasive wheel for cutting the opposite lower side.



- First lateral cut on the top half of the pipe



- Determine and mark direction of cut
 - Determine sequence of cuts
- Outer diameter is smaller than the maximum cutting depth**



- Make **one** cut from the top to the bottom

Outer diameter is greater than the maximum cutting depth

Plan first, then cut. **Several** cuts are needed – correct sequence is important.

- Turn guard at rear stop

Cutting Wheels

Abrasive wheels are exposed to extremely high loads especially during freehand cutting.


- Therefore only for use of approved and correspondingly labeled abrasive wheels with hand-held machines as per EN 13236 (diamond) or EN 12413 (composite resin). Note maximum permissible speed of the abrasive wheel
- risk of accident!**

The abrasive wheels, which have been developed by STIHL in cooperation with renowned manufacturers of abrasive wheels, are of high quality and tailored precisely to the respective intended use as well as the engine performance of the cut-off machine.


- They are of consistently outstanding quality.

Transport and storage


- Do not expose abrasive wheels to direct sunshine or other thermal stresses during transport and storage
- Avoid jolting and impacts
- Stack abrasive wheels flat on a level surface in the original packaging in a dry place where the temperature is as constant as possible
- Do not store abrasive wheels in the vicinity of aggressive fluids
- Store abrasive wheels in a frost-free place




Type:	<ul style="list-style-type: none"> for dry applications for wet applications
	The proper selection and use of composite resin cutting wheels ensures economical use and avoids accelerated wear. The product code which appears
	<ul style="list-style-type: none"> on the label and on the packaging (table with recommendations for use) is an aid to selection
	STIHL composite resin cutting wheels are suitable, depending on the version, for cutting the following materials:



- Always make severing cuts so that the abrasive wheel is not pinched



- Use wedges and/or leave ridges that are broken after cutting




- If the severed part remains in the recess after cutting (due to wedges, ridges used), do not make any further cuts – break the severed part

Diamond Abrasive Wheels

Never use diamond abrasive wheels with side plating as they jam in the cut and can result in extreme kickback – **Risk of accident!**

Product Codes




For wet applications.

The proper selection and use of diamond abrasive wheels ensures economical use and avoids accelerated wear. The product code which appears

- on the label and
 - on the packaging (table with recommendations for use) is an aid to selection
- STIHL diamond abrasive wheels are suitable, depending on the version, for cutting the following materials:


- Asphalt
- Concrete
- Stone (hard stone)
- Abrasive concrete
- Fresh concrete
- Clay brick
- Clay pipe
- Ductile cast iron pipe

Do not cut any other materials – **Risk of accident!**



An excessively high radial run-out deviation (**A**) overloads individual diamond segments, which overheat in the process. This can lead to stress cracks in the parent wheel or to annealing of individual segments. Deviations in axial run-out (**B**) result in higher thermal loading and wider cuts.

Undercut




Do not cut into the base course (frequently chipped stones and gravel) when cutting roadway pavement – cutting in chipped stones and gravel is revealed by light-colored dust – excessive undercut may occur as a result – **Danger of shattering!**

A faultless spindle bearing of the cut-off machine is necessary for a long service life and efficient functioning of the diamond abrasive wheel.

Using the abrasive wheel on a cut-off machine with a faulty spindle bearing can lead to deviations in radial and axial run-out.

Built-up edges, sharpen



If work continues with dull segments, these may soften due to the high heat generated – the parent wheel is annealed and its strength is compromised – this can lead to stresses that are clearly recognizable by gyrations of the abrasive wheel. Do not continue to use the abrasive wheel –


Risk of accident!

Built-up edges can form:

- when cutting extremely hard materials, e. g., granite
- with incorrect handling, e. g., excessive feed effort

Built-up edges increase vibration, reduce cutting performance, and cause formation of sparks.

At the first signs of built-up edges immediately "sharpen" the diamond abrasive wheel – to do this, briefly cut through abrasive material such as sandstone, aerated concrete or asphalt. Addition of water prevents the formation of built-up edges.



Troubleshooting

Abrasive wheel

Defects	Cause	Remedy
ragged edges or cut surfaces, crooked cut	Deviation in radial or axial run-out	Contact a servicing dealer ¹⁾
heavy wear on the sides of the segments	Abrasive wheel gyrates	use a new abrasive wheel
ragged edges, crooked cut, no cutting performance, generation of sparks	Abrasive wheel is dull; built-up edges with abrasive wheels for stone	Sharpen abrasive wheels for stone by briefly cutting through abrasive materials; replace abrasive wheel for asphalt with a new one
poor cutting performance, high segment wear	Abrasive wheel is turning in the wrong direction	Mount abrasive wheel so that it turns in the right direction
Breakdowns or tears in the parent wheel and segment	Overloading	use a new abrasive wheel
Undercut	Cutting in the wrong material	use new abrasive wheel; observe separating layers of various materials

1) STIHL recommends STIHL servicing dealers



Electronic Water Control

STIHL cut-off machines may be equipped with an electronic water control system.

The electronic water control makes it possible to feed the optimum amount of water to the abrasive wheel. No water is fed to the abrasive wheel during idling.

Before starting work

- Familiarize yourself with the sequence of motions while the engine is switched off



remains on the rear handle while doing so, the left hand always remains on the handlebar

If the cut-off machine is idling after use, no more water will be fed to the abrasive wheel – the electronic water control, however, remains activated. With continued use, the last quantity of water set will be fed to the abrasive wheel again automatically.

If the engine is stopped and restarted, the electronic water control is switched off.

For installation on the STIHL FW 20 cut-off machine cart

If the cut-off machine is mounted on the STIHL FW 20 cut-off machine cart in combination with the water tank, feed the maximum amount of water.

Using the electronic water control

- Start engine, see "Starting / Stopping the Engine"
- Tap on the (+) button or (-) button with the thumb of the right hand – the right hand always remains on the rear handle while doing so
- All of the control panel buttons can be operated with the thumb of the right hand – the right hand always remains on the rear handle while doing so
- The left hand always remains on the handlebar


During use, the set amount of water is fed to the abrasive wheel.

When the engine is running, it is possible to activate / deactivate the electronic water control and adjust the water flow.

Control panel

- Adjust water flow if necessary – to do so, tap on the (+) button or (-) button with the thumb of the right hand until the correct water quantity is attained – the right hand always

- Remove the coupling sleeve (1)
- Unscrew "water connection with screen" (2) and rinse under running water – the screen remains on the water connection



Maintenance and care

If too little water or no water is fed to the abrasive wheel during use although the electronic water control has been activated:

If too little water or no water is fed to the abrasive wheel although the screen has been cleaned, visit your servicing dealer.

Assembling the cast arm and guard


The "cast arm with guard" is mounted on the inboard side by the manufacturer. The "cast arm with guard" can also be mounted on the outboard side depending on requirements.

Assembly on the inboard side is recommended for freehand cutting on account of the better balance.

Outboard mounting


Disassemble the cutting wheel (see "Fitting / replacing an cutting wheel")

Remove water attachment




- Unscrew the banjo bolt (1) with the combination wrench – in the process, remove the square nut from the inside of the guard from the guide
- Remove the water hose (2) with connector from the adjusting lever (3)
- Pull the water hose (2) out of the guide (arrows) in the V-belt guard

Removing the adjusting lever




- Unscrew the banjo bolt (1) with the combination wrench and remove it together with the seal – in the process, remove the square nut from the inside of the guard from the guide
- Remove screw (2)
- Turn the adjusting lever (3) upwards and remove

Slackening the V-belt




- Unscrew the nuts (1) – do not remove them
- Turn the tensioning nut (2) counterclockwise with the combination wrench – approx. 1/4 turn, as far as it will go = 0


Removing the V-belt guard



- Remove screw (1)
- Raise the V-belt guard (2) slightly and pull it off to the front




- Remove the V-belt (3) from the front pulley (4)




- Unscrew the nuts (1)
- Remove the "starter cover with rewind starter" (2)
- Remove the "cast arm with guard" (3) from the studs


Preparing the "cast arm with guard" for outboard mounting



- Unscrew stop pin (1)




- Turn the guard so that it is in the position shown (see picture)
- Screw in and tighten the stop pin (1)
- Move the adjusting lever (2) to position A
- Screw in the bolt (3) and tighten up
- Unscrew the bolt (4) of the limit stop (5)
- Remove the limit stop (5)



- Turn the "cast arm with guard" so that the guard is on the outboard side
- Insert limit stop (5) – align the hole in the limit stop with the hole in the cast arm
- Screw in the bolt (4) and tighten up

- Insert the square nut into the guide in the guard and hold it in place
- Screw in the shorter banjo bolt (6) and washer at the adjusting lever and tighten up with the combination wrench

Mount "cast arm with guard" – guard on the outboard side




- Press the oblong holes (1) in the "cast arm with guard" on to the studs (2), guiding the ribbed V-belt over the front pulley
- The belt action must run smoothly.
- The belt tensioner (3) must sit close to the lug (4)




The belt action must run smoothly.

- The belt tensioner (3) must sit close to the lug (4)



- Fit the support with the longer banjo bolt on the adjusting lever (3) – screw in the banjo bolt and tighten with the combination wrench
- Insert the water hose into the guide in the V-belt guard (arrow) from the shut-off cock towards the guard – avoid tight radiuses


Checking the adjustment range of the guard



- Rotate the guard forwards and backwards as far as possible – adjustment range (A) must be limited by the stop pin


Continue as described in the chapter "Tensioning the V-belt".

- Insert the "starter cover with rewind starter" (5) over the studs (2)
- Tighten up the nuts (6) by hand



- Push the V-belt guard (7) into place
- Screw in the bolt (8) and tighten up

Connect water connection




- Insert the longer banjo bolt (1) through the connector (2) of the water attachment – observe the position of the connector
- Insert the square nut into the guide in the guard and hold it in place

Inboard mounting

- Disassemble the cutting wheel (see "Fitting / replacing an cutting wheel")
- Remove water attachment
- Remove the adjusting lever
- Slacken the V-belt
- Remove the V-belt guard
- Remove the "cast arm with guard"


Preparing the "cast arm with guard" for inboard mounting



- Unscrew the screw (1) of the limit stop (2)
- Remove the limit stop (2)


- Turn the "cast arm with guard" so that the guard is on the inboard side
- Insert limit stop (2) – align the hole in the limit stop with the hole in the cast arm

Check the adjustment range of the guard



Continue as described in the chapter "Tensioning the V-belt".


- Screw in the bolt (1) and tighten up
- Unscrew stop pin (3)



- Turn the guard so that it is in the position shown (see picture)
- Screw in and tighten the stop pin (3)
- Install the adjusting lever
- Mount "cast arm with guard" – guard on the inboard side
- Install the V-belt guard
- Connect water connection

Tensioning the ribbed V-belt

This machine is equipped with an automatic spring-action V-belt tensioning device.




- Prior to tensioning of the ribbed v-belt, the nuts (1) must be loosened and the arrow on the tensioning nut (2) must point to 0.
- otherwise loosen the nuts (1) and the tensioning nut (2) with the combination wrench counterclockwise – approx. 1/4 turn, as far as possible = 0

⚠ WARNING

The tensioning nut is spring-loaded – hold the combination wrench securely.

- Turn the tensioning nut clockwise approx. 1/8 turn – the tensioning nut will be engaged by the spring
- Continue turning approx. 1/8 turn – up to the stop




NOTICE
Do not turn the combination wrench further by force.

The ribbed V-belt is automatically tensioned by the force of the spring in this position.

- Remove the combination wrench from the tensioning nut
- Tighten up the nuts (1)

Retensioning the ribbed V-belt




- to tighten the ribbed v-belt, fit the combination wrench over the tensioning nut as illustrated

- Undo the nuts (1)
- The V-belt is automatically tensioned by the force of the spring.
- Tighten up the nuts (1) again

Mounting an Abrasive Wheel

The engine must be switched off for fitting or replacement – set slide control to **STOP** or 0.

Blocking the shaft



- Slide the locking pin (1) through the bore in the V-belt guard
- Turn the shaft with the combination wrench until the locking pin (1) engages in the bore behind the guard

The V-belt is retensioned without the aid of the tensioning nut.


- Undo the nuts (1)

The V-belt is automatically tensioned by the force of the spring.

Fitting a new cutting wheel

⚠ WARNING

Never use two cutting wheels at the same time. The uneven wear creates a **risk of breaking and an injury hazard!**




- Fit the new cutting wheel (4)

⚠ WARNING

Note the arrows indicating the direction of rotation on diamond cutting wheels.

- Fit the front thrust washer (3). The catches of the front thrust washer (3) must engage in the shaft grooves.
- Screw in the hexagon bolt and **tighten it** with the combination wrench – if using a torque wrench, refer to the "Specifications" for the tightening torque
- Draw the locking pin out of the V-belt guard



- Use the combination wrench to loosen and remove the hexagon head screw (2)
- Remove the front thrust washer (3) from the shaft together with the cutting wheel

Fuel

Gasoline with an ethanol content of more than 10% can cause running problems in engines with a manually adjustable carburetor and should not be used in such engines.

Your engine requires a mixture of gasoline and engine oil.



WARNING
For health reasons, avoid direct skin contact with gasoline and avoid inhaling gasoline vapor.

Engines equipped with M-Tronic deliver full power when run on gasoline with an ethanol content of up to 25% (E25).

STIHL MotoMix

STIHL recommends the use of STIHL MotoMix. This ready-to-use fuel mix contains no benzol or lead, has a high octane rating and ensures that you always use the right mix ratio.

STIHL MotoMix uses STIHL HP Ultra two-stroke engine oil for an extra long engine life.

MotoMix is not available in all markets.

Mixing Fuel

Storing Fuel

Store fuel only in approved safety-type fuel canisters in a dry, cool and safe location protected from light and the sun.

Fuel mix ages – only mix sufficient fuel for a few weeks work. Do not store fuel mix for longer than 30 days. Exposure to light, the sun, low or high temperatures can quickly make the fuel mix unusable.

STIHL MotoMix may be stored for up to 2 years without any problems.

- Thoroughly shake the mixture in the canister before fueling your machine.



WARNING
Pressure may build up in the canister – open it carefully.

- Clean the fuel tank and canister from time to time.

Dispose of remaining fuel and cleaning fluid properly in accordance with local regulations and environmental requirements.

Examples

Gasoline	STIHL engine oil 50:1
Liters	Liters
1	0.02 (20)
5	0.10 (100)
10	0.20 (200)
15	0.30 (300)
20	0.40 (400)
25	0.50 (500)

Gasoline

Unsuitable fuels or lubricants or mix ratios other than those specified may result in serious damage to the engine. Poor quality gasoline or engine oil may damage the engine, sealing rings, hoses and the fuel tank.

- Use a canister approved for storing fuel. Pour oil into canister first, then add gasoline and mix thoroughly.

Use only high-quality **brand-name** gasoline with a minimum octane rating of 90 – leaded or unleaded.

Fueling




Refueling

Take care not to spill fuel while fueling and do not overfill the tank. STIHL recommends use of the STIHL filling system for fuel (special accessory).

If the cap can be removed or the markings do not align, close the cap again – see sections "Closing the cap" and "Checking the lock".

Changing the fuel pickup body every year




Closing the filler cap


- Before fueling, clean the filler cap and the area around it so that dirt cannot fall into the tank
- Always position the machine so that the filler cap is facing upwards

! WARNING

Never use a tool to open the bayonet filler cap. The cap can be damaged and fuel may escape.




Opening the twist lock



- Press the filler cap down as far as possible by hand, then turn it counterclockwise (approx. 1/8 turn) and remove


- Drain the fuel tank
- Pull the fuel pickup body out of the tank with a hook and disconnect it from the hose
- Connect a new fuel pickup body to the hose
- Return the fuel pickup body to the tank




- Grip the cap – the cap is closed properly if it cannot be removed and the markings (arrows) on the cap and fuel tank are aligned

Starting / Stopping the Engine


Versions with decompression valve



- Press the button (5) of the decompression valve before each starting procedure



- Set the choke (4) according to the engine temperature
 - I** If engine is **cold**
 - if the engine is **warm** (even if the engine is already running but is still cold or if the warm engine was shut off for less than 5 min)
 - if the engine is **hot** (if the hot engine was switched off for longer than 5 min)



- Press throttle trigger lockout (1) and throttle trigger (2) simultaneously
- Hold both triggers down
- Move the slide control (3) to **START** and hold it in position too
- Release the throttle trigger, slide control and throttle trigger lockout in succession – **starting throttle position**


For all versions

ground or any objects. There must not be anyone within the swivel range of the cut-off machine


- Make sure you have a firm footing
- Press the cut-off machine firmly against the ground, holding the handle with your left hand, thumb wrapped round the handle
- Press the cut-off machine against the ground with the right knee on the shroud
- Pull the starter grip slowly with your right hand until you feel it engage – then give it a brisk strong pull – do not pull out the starter rope all the way

**NOTICE**


Do not let the starter grip snap back – it may break! Guide it back into the housing in the opposite direction so that it can rewind properly.



- Press the bulb (6) of the manual fuel pump 7-10 times – even when the bulb is still filled with fuel

Starting


- Place the cut-off machine carefully on the ground, ensuring that the abrasive wheel cannot touch the

When the engine has turned over for the first time

- Set the choke lever (4) to
- Press the button of the decompression valve (depending on version)
- continue cranking

Once the engine is running

- Squeeze throttle trigger fully and let engine run at full throttle for approx. 30 s
- When it has warmed up, set the choke lever to



- The slide control (3) moves to the normal positionI when the throttle trigger is squeezed

- If the carburetor has been set correctly, the abrasive wheel should not rotate when the engine is idling.
- The cut-off machine is now ready for use.

Switching off the engine


- Set the choke lever in accordance with the engine temperature
- Restart the engine

Air Filter System

Basic information

The average filter life is more than 1 year. Do not dismantle the filter cover or fit a new air filter unless there is a noticeable loss of engine power.

In the long-life air filter system with the cyclone pre-separation system, dirty air is drawn in and deliberately rotated. The larger and heavier particles carried in the air are thus expelled and extracted. Only pre-cleaned air enters the air filter system and the result is extremely long filter life.



- Slide control (3) to **STOP** or 0

Additional hints on starting

If the engine does not start

The choke lever was not returned to $\overline{\text{I}}$ in time after the engine turned over for the first time.

- Slide control to **START = starting throttle position**

- Set the choke lever to $\overline{\text{I}} = \text{warm start}$, even if the engine is cold
- Pull the starter rope through 10-20 times to ventilate the combustion chamber

- Restart the engine

If the tank has been drained completely


- Refuel
- Press the manual fuel pump bulb 7-10 times – even if it is full of fuel

Replacing the air filter

Only high-quality air filters should be used, to protect the engine against ingress of abrasive dust.

Only if there is a noticeable loss of engine power

STIHL recommends the use of genuine STIHL air filters. The high quality of these parts will ensure trouble-free operation, a long service life for the engine and extremely long filter life.



Adjusting the Carburetor

Basic information

The ignition system of this cut-off machine is equipped with an electronic speed limiter. The maximum speed cannot be increased beyond a specified limit.


The carburetor is equipped with a factory-installed standard setting.

The carburetor has been adjusted for optimum performance and fuel efficiency in all operating states.

Preparing the machine

- Switch off engine
- Check the air filter – clean or replace it if necessary


- Choke lever to
- Undo the screws (1).
- Remove the filter cover (2) and clean it
- Remove the main filter (3)
- Remove the auxiliary filter (4) – ensuring that dirt does not enter the intake area
- Clean the filter area
- insert new auxiliary filter and new main filter
- Refit the filter cover
- Tighten down the screws

Standard setting**Abrasive cutting wheel rotates when idling**

- Turn the idle speed adjusting screw (LA) counterclockwise until the abrasive cutting wheel stops rotating – then give the screw another full turn in the same direction
- WARNING**
If the abrasive cutting wheel continues to rotate in idle even after adjustment, have the cut-off machine checked by a servicing dealer.
- Turn the high speed adjusting screw (H) counterclockwise as far as possible – max. 3/4 turn
- Turn the low speed adjusting screw (L) clockwise as far as possible – then turn it 3/4 turn counterclockwise

Setting the idle speed

- Carry out the standard setting
- Start engine and let it warm up

**Engine stops when idling**

- Turn the idle speed adjusting screw (LA) clockwise until the abrasive cutting wheel begins to turn – then turn it back 1 turn

Correcting the carburetor setting for use at high altitudes

- Turn the idle speed adjusting screw (LA) counterclockwise until the abrasive cutting wheel stops rotating – then give the screw another full turn in the same direction
- Allow engine to warm up
- Turn the high speed adjusting screw (H) slightly clockwise (leaner)
- max. up to the stop



NOTICE
After descending from a high altitude, restore the carburetor setting to the standard setting.

If you make the setting too lean it will increase the risk of engine damage through lack of lubrication and overheating.

Idle speed cannot be increased sufficiently via the idle speed adjusting screw (LA), engine stops when changing from part-load to idle speed

The idle setting is too rich.

- Turn the low speed adjusting screw (L) approx. 1/4 turn counterclockwise until the engine runs and accelerates smoothly – max. up to the stop

Whenever the low speed adjusting screw (L) has been adjusted, it is usually also necessary to readjust the idle speed adjusting screw (LA).

Spark Plug


- Use resistor type spark plugs with a properly tightened adapter nut.

Checking the Spark Plug


- If the engine is down on power, difficult to start or runs poorly at idle speed, first check the spark plug.
- Fit a new spark plug after about 100 operating hours – or sooner if the electrodes are badly eroded. Install only suppressed spark plugs of the type approved by STIHL – see "Specifications".

Removing the spark plug


- Switch off the engine – move stop switch to **STOP** or 0



- Unscrew screw (1) and remove cap (2) – screw (1) is secured in the cap (2) to prevent loss



- Remove the spark plug boot (3).
- Unscrew the spark plug (4).




Clean dirty spark plug.

- Check electrode gap (A) and readjust if necessary – see "Specifications".

- Rectify the problems which have caused fouling of the spark plug.

Possible causes are:


- Too much oil in fuel mix.
- Dirty air filter.
- Unfavorable running conditions.




WARNING

Arcing may occur if the adapter nut (1) is loose or missing. Working in an easily combustible or explosive atmosphere may cause a fire or an explosion. This can result in serious injuries or damage to property.


Replacing the V-belt




- Unscrew the nuts (1)
- Remove the starter cover (5)
- Do not remove the "cast arm and guard" (6) – hold it in place on the studs until the starter cover is fitted back in position
- Remove the defective V-belt



- Fit the starter cover (5) over the studs (10)
- Tighten up the nuts (1) by hand
- Push the V-belt guard (4) into place
- Screw in the bolt (3) and tighten up
- Insert the water hose into the guide in the V-belt guard (arrow) from the shut-off cock towards the guard – avoid tight radiiuses
- Continue as described in the chapter "Tensioning the V-belt".




- Undo the nuts (1)
- Turn the tensioning nut (2) counterclockwise with the combination wrench – approx. 1/4 turn, as far as it will go = 0




- Carefully insert the new V-belt (7) on the V-belt pulley (8) on the engine and the front V-belt pulley (9)



NOTICE
The belt action must run smoothly.



- Remove screw (3)
- Raise the V-belt guard (4) slightly and pull it off to the front
- Remove the V-belt from the front pulley




- Pull the water hose out of the guide in the V-belt guard
- Remove screw (3)
- Raise the V-belt guard (4) slightly and pull it off to the front
- Remove the V-belt from the front pulley

Cut-off Machine Cart

Storing the Machine

If the machine is to remain out of use for approx. 3 months or more

- Drain and clean the fuel tank in a well ventilated place
- Dispose of fuel in accordance with the regulations and having regard for the environment
- Run the engine until the carburetor is dry, this helps to prevent the carburetor diaphragms sticking together
- Remove the abrasive wheel
- Thoroughly clean the machine
- Store machine in a safe and dry place. Protect against unauthorized use (e.g., by children)



The cut-off machine can be mounted on the STIHL cut-off machine cart FW 20 (special accessory) in a few easy steps.

The cut-off machine cart makes it easier to

- repair damaged roadways
- apply roadway markings
- cut expansion joints

Maintenance and Care

English

The information applies in normal operating conditions. The specified intervals must be shortened accordingly when working for longer than normal or under difficult cutting conditions (extensive dust, etc.).

		Before starting work		At the end of work and/or daily		Whenever tank is refilled		Monthly		Yearly		If faulty		As required if damaged								
		Visual inspection (condition, leaks)	Clean	Check operation	Inspect	Have them repaired by a specialist dealer ¹⁾	Inspect	Replace	Clean	Clean / re-tensioning	Replace	Replace	Replace	Replace	Inspect	Repair by authorized dealer ¹⁾	Check idle adjustment – abrasive cutting wheel must not rotate	Readjust idle speed	Adjust electrode gap	Replace after 100 hours' operation	Tighten	
Complete machine	Clean	X	X	X																		
Controls	Inspect																					
Manual fuel pump (if present)	Have them repaired by a specialist dealer ¹⁾																					
Fuel pickup body in fuel tank	Inspect																					
Fuel tank	Clean																					
V belt	Clean / re-tensioning																					
Air filter (all filter components)	Replace																					
Cooling air intake slits	Clean																					
Cylinder fins	Have them cleaned by a specialist dealer ¹⁾																					
Water connection	Inspect																					
Carburetor	repair by authorized dealer ¹⁾																					
Spark plug	Check idle adjustment – abrasive cutting wheel must not rotate	X																				
All accessible screws, nuts and bolts (not adjusting screws)	Readjust idle speed																					
	Adjust electrode gap																					
	Replace after 100 hours' operation																					
	Tighten	X																				

	The information applies in normal operating conditions. The specified intervals must be shortened accordingly when working for longer than normal or under difficult cutting conditions (extensive dust, etc.).	
	As required	As required
Antivibration elements	Inspect Have them replaced by a servicing dealer ¹⁾	×
Abrasive cutting wheel	Inspect Replace	×
Supports/rubber buffers (underneath the machine)	Inspect Replace	×
Safety information label	Replace	×
	Whenever tank is refilled At the end of work and/or daily	When ever tank is refilled At the end of work and/or daily
	Before starting work	Before starting work
	Weekly	Weekly
	Monthly	Monthly
	Yearly	Yearly
	If faulty	✓
	If damaged	✓

¹⁾ STIHL recommends the STIHL servicing dealer

Minimize Wear and Avoid Damage

Observing the instructions in this manual helps reduce the risk of unnecessary wear and damage to the power tool. The power tool must be operated, maintained and stored with the due care and attention described in this owner's manual.

- The user is responsible for all damage caused by non-observance of the safety precautions, operating and maintenance instructions in this manual. This includes in particular:
 - Alterations or modifications to the product not approved by STIHL.
 - Using tools or accessories which are neither approved or suitable for the product or are of a poor quality.
 - Using the product for purposes for which it was not designed.
 - Using the product for sports or competitive events.
- Consequential damage caused by continuing to use the product with defective components.

servicing dealer. STIHL dealers are regularly given the opportunity to attend training courses and are supplied with the necessary technical information.

If these maintenance operations are not carried out as specified, the user assumes responsibility for any damage that may occur. Among other parts, this includes:

- Damage to the engine due to neglect or deficient maintenance (e.g. air and fuel filters), incorrect carburetor adjustment or inadequate cleaning of cooling air inlets (intake ports, cylinder fins).
- Corrosion and other consequential damage resulting from improper storage.
- Damage to the machine resulting from the use of poor quality replacement parts.

Wear parts

Some parts of the machine are subject to normal wear and tear even when the machine is used in conformity with its intended use. These parts must be replaced in due time, depending on the nature and duration of use. These include, among others:


- Clutch, V-belt
- Abrasive wheels (all types)
- Filters (air, fuel)
- Rewind starter
- Spark plug
- Components of anti-vibration system

Maintenance Work

All the operations described in the "Maintenance Chart" must be performed on a regular basis. If these maintenance operations cannot be performed by the owner, they should be performed by a servicing dealer.

STIHL recommends that you have servicing and repair work carried out exclusively by an authorized STIHL

Main Parts



- 1 Rear handle
2 Throttle trigger lockout
3 Throttle trigger
4 Slide control
5 Starter grip
6 Carburetor adjusting screws
7 Filler cap
8 Water connection
9 Tensioning nut
10 Adjusting lever
11 Abrasive cutting wheel
12 Front thrust washer
13 Deflector
14 Muffler
15 Handlebar
16 Decompression valve¹⁾
17 Cap for spark plug boot
18 Choke shutter lever
19 Manual fuel pump
20 Filter cover
Machine no.
A Safety information label
B Safety information label
C Safety information label


1) According to version

Specifications		Fuel system		Composite resin abrasive wheels	
Engine		All-position diaphragm carburetor with integral fuel pump	Fuel tank capacity:	Minimum outside diameter of thrust washers: 103 mm	Max. depth of cut: 100 mm
TS 410		STIHL single cylinder two-stroke engine	Air filter	Diamond abrasive wheels	Minimum outside diameter of thrust washers: 103 mm
Displacement:	66.7 cm ³	Main filter (paper filter) and flocked wire mesh auxiliary filter	Max. depth of cut:	Max. outside diameter of thrust washers: 103 mm	Max. depth of cut: 100 mm
Cylinder bore:	50 mm				
Piston stroke:	34 mm				
Engine power accord- ing to ISO 7293:	3.2 kW (4.4 HP) at 9000 rpm	Weight			
Idle speed:	2500 rpm	without fuel, without abrasive wheel, with water attachment			
Max. spindle speed to ISO 19432:	5080 rpm	TS 410: 9.4 kg	Outside diameter: 350 mm		
		TS 420: 9.6 kg	Max. thickness: 4.8 mm		
TS 420		Without fuel, without abrasive wheel, with electronic water control	Bore diameter/spindle diameter: 20 mm		
Displacement:	66.7 cm ³	TS 410: 9.9 kg	Tightening torque: 30 Nm		
Cylinder bore:	50 mm	TS 420: 10.1 kg			
Piston stroke:	34 mm				
Engine power accord- ing to ISO 7293:	3.2 kW (4.4 HP) at 9000 rpm	Abrasive wheels	Composite resin abrasive wheels		
Idle speed:	2500 rpm		Minimum outside diameter of thrust washers: ¹⁾ 103 mm		
Max. spindle speed to ISO 19432:	4880 rpm	The quoted maximum permissible operating speed of the abrasive wheel must be greater than or equal to the maximum spindle speed of the cut-off machine used.	Maximum cutting depth: ³⁾ 125 mm		
			1) For Japan 118 mm		
			2) For Australia 118 mm		
			3) When using thrust washers with an outside diameter of 118 mm, the maximum cutting depth is reduced to 116 mm		
Ignition system			Diamond abrasive wheels		
Electronic magneto ignition			Minimum outside diameter of thrust washers: ¹⁾ 103 mm		
Spark plug (suppressed):	Bosch WSR 6 F	Outside diameter: 103 mm	Maximum cutting depth: ³⁾ 125 mm		
Electrode gap:	0.5 mm	Max. thickness: 4.8 mm	1) For Japan 118 mm		
		Bore diameter/spindle diameter: 20 mm	3) When using thrust washers with an outside diameter of 118 mm, the maximum cutting depth is reduced to 116 mm		
		Tightening torque: 30 Nm			

Sound and vibration levels	Exhaust Emissions	Maintenance and Repairs																		
<p>For further details concerning compliance with the Physical Agents Directive Vibration 2002/44/EC, see www.stihl.com/vib/</p> <p>Sound pressure level $L_{p\text{eq}}$ to ISO 19432</p> <table> <tr> <td>TS 410:</td> <td>98 dB(A)</td> </tr> <tr> <td>TS 420:</td> <td>98 dB(A)</td> </tr> </table> <p>Sound power level L_w to ISO 19432</p> <table> <tr> <td>TS 410:</td> <td>109 dB(A)</td> </tr> <tr> <td>TS 420:</td> <td>109 dB(A)</td> </tr> </table> <p>Vibration level $a_{hv,\text{eq}}$ to ISO 19432</p> <table> <tr> <td>Handle,</td> <td>Handle,</td> </tr> <tr> <td>Handle, left</td> <td>Handle, right</td> </tr> <tr> <td>TS 410:</td> <td>3.9 m/s²</td> <td>3.9 m/s²</td> </tr> <tr> <td>TS 420:</td> <td>3.9 m/s²</td> <td>3.9 m/s²</td> </tr> </table> <p>The K-factor in accordance with Directive 2006/42/EC is 2.0 dB(A) for the sound pressure level and sound power level; the K-factor in accordance with Directive 2006/42/EC is 2.0 m/s² for the vibration level.</p>	TS 410:	98 dB(A)	TS 420:	98 dB(A)	TS 410:	109 dB(A)	TS 420:	109 dB(A)	Handle,	Handle,	Handle, left	Handle, right	TS 410:	3.9 m/s ²	3.9 m/s ²	TS 420:	3.9 m/s ²	3.9 m/s ²	<p>The CO₂value measured in the EU type approval procedure is specified at www.stihl.com/co2.</p> <p>The measured CO₂value was determined on a representative engine in accordance with a standardized test procedure under laboratory conditions and does not represent either an explicit or implied guarantee of the performance of a specific engine.</p> <p>The applicable exhaust emission requirements are fulfilled by the intended usage and maintenance described in this instruction manual. The type approval expires if the engine is modified in any way.</p>	<p>Users of this machine may only carry out the maintenance and service work described in this user manual. All other repairs must be carried out by a servicing dealer.</p> <p>STIHL recommends that you have servicing and repair work carried out exclusively by an authorized STIHL servicing dealer. STIHL dealers are regularly given the opportunity to attend training courses and are supplied with the necessary technical information.</p> <p>When repairing the machine, only use replacement parts which have been approved by STIHL for this power tool or are technically identical. Only use high-quality replacement parts in order to avoid the risk of accidents and damage to the machine.</p> <p>STIHL recommends the use of original STIHL replacement parts.</p> <p>Original STIHL parts can be identified by the STIHL part number, the STIHL logo and the STIHL parts symbol  (the symbol may appear alone or small parts).</p>
TS 410:	98 dB(A)																			
TS 420:	98 dB(A)																			
TS 410:	109 dB(A)																			
TS 420:	109 dB(A)																			
Handle,	Handle,																			
Handle, left	Handle, right																			
TS 410:	3.9 m/s ²	3.9 m/s ²																		
TS 420:	3.9 m/s ²	3.9 m/s ²																		
		<p>REACH</p> <p>REACH is an EC regulation and stands for the Registration, Evaluation, Authorisation and Restriction of Chemical substances.</p> <p>For information on compliance with the REACH regulation (EC) No. 1907/2006 see www.stihl.com/reach.</p>																		

Disposal

Observe all country-specific waste disposal rules and regulations.



EC Declaration of Conformity

ANDREAS STIHL AG & Co. KG
Badstr. 115
D-71336 Waiblingen

Germany
declare in exclusive responsibility that
the product
retained by:

ANDREAS STIHL AG & Co. KG
Product approval

The year of construction and the serial
number are shown on the machine.

Done at Waiblingen, 03.12.2018
ANDREAS STIHL AG & Co. KG
pp

Thomas Elsner

Thomas Elsner
Head of Product Management and
Services

CE

The measured and guaranteed
equivalent sound power level has been
determined in accordance with Directive
2000/14/EC, Annex V, and standard
ISO 3744.

Measured sound power level


all TS 410:	114 dB(A)
all TS 420:	114 dB(A)

0458-370-0121-F

englisch



www.stihl.com



0458-370-0121-F