## Useful Reference Points • www.hae.org.uk/businessguard

Betore Starting Work.

## **AAHA XHOW**

- chinders. ignite fumes from petrol, or gas there is a danger of explosion. It will Do not use this pressure washer where 1
- always be required. extraction ventilation will almost has been fully assessed. Mechanical suitability and the ventilation required use it in other indoor situations it its use it in domestic premises and only carbon monoxide poisoning. Never confined spaces could cause Using this equipment indoors or in .s
- and water spray. Use a wash bay, or Protect other people from the noise °t and that no-one is near to distract you. Make sure that the area is clear and safer
- Set up the work area so that there is no **'**G drainage for the waste water. erect barriers. Make sure there is good
- any electricity supply socket. danger of water being sprayed onto

## **SHOTAHAGO**

**bd** 

v:112016

- Particular jobs or environments may require a higher level of protection. whenever you use this pressure washer. . worn. ed bluode that muminim protective equipment (PPE) are the 1. The following items of personal
- You must wear an impact resistance . S
- You should wear overalls, boots and 31 .eninosin
- gloves that are waterproor.
- need to wear appropriate personal Anybody working near to you will also °t

protective equipment.

**3YT TEB Iludilos** The Crescent Birmingham Business Park noo sinegen uce Association Europe

:lism3

31

· Z

11


-9

**'**G

·t

3.

.S.



water supply is.

**WATER SUPPLY** 

stop it safely.

setting-up the machine.

away to reduce noise.

vehicles may run over it.

RESSURE WASHER

mail@hae.org.uk 44 (0) 121 333 4109

the instructions supplied with them. Use only the recommended detergent recommended by the three company.

If using chemicals or detergents, follow

in any doubt about how clean your

You must use a suitable filter if you are

If your supply is from a water tank

you must know how to control it and

controls. Before you start the washer

Make shie you understand all of the

connections get dirty when you are

Make sure that none of the hose

Make sure that all the pressure hose connections are firm and tight.

supplied by the hire company. These allow you to site your machine further

Extension hoses may have been

machine. Ensure it is laid out safely with no kinks, away from where

Use only the hose supplied with the

washer – contact the hire company.

Check your machine, engine, pressure water hoses, and equipment. If anything is fo

make sure the water is clean.

to have arisen t

is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perc nave arisen from the use of any such document/material. Only Acts of Parliament and Statutory Ins from the use of any such document/material. Only Acts of Parliament and Statu have the force of law and only the courts can authoritatively interpret the law.

Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting materia



- alcohol

- This pressure washer is designed for operation by an able bodied adult. Anyone with either
- Waterproof gloves

0814 Safety Guidance

It is important to read all of this leaflet

**BEFORE** you use the Pressure Washer

1. Diesel fuel is highly flammable. Take care not to cause a fire or

This pressure washer is designed for high pressure water

The action of this pressure washer can cause injury or damage

Familiarise yourself with how the equipment works before starting work.

You should have at least the following items of personal protective equipment

if the equipment is not used in a careful and controlled way.

Think ahead to make sure you will always be working safely.

Ear muffs or plugs giving protection for levels up to 88 dB(A)

**Pressure Washer** 

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment

- 7.
- This equipment must not be used by minors. Or by anyone under the influence of drugs or

Impact resistant visor or goggles:

- Waterproof overalls

- Waterproof boots

explosion.

washing.

2.

3.

4.

5.

1

.nonisoq

мојад цаліб

.4

31

.s

٦.

-8

-9

·+

3

٦.

punoj

übiu

44 (0) 121 380 4600

44 (0) 121 333 4109

Move the STOP control to the RUN

Check the oil and fuel levels before

Otherwise, follow the instructions

If the hire company has given you

This section describes the starting

move your fuel can to a safe cool place.

It any fuel is spilt on your clothes,

Wipe any fuel off the machine. Dispose

refuelling. Do not spill any fuel on

around it to prevent dirt talling into the

Clean the filter cap and the area

If possible, move the machine away

2. Stop the engine and let it cool down.

5. Use a funnel and clean petrol when

9. Put all fuel caps back on properly, and

λ. If any fuel is spilt on the ground, wipe it

change them straight away.

of fuel soaked cloth carefully.

special instructions, follow the

procedure for most diesel engines.

you try to start the engine.

**STARTING THE ENGINE** 

up or cover it with soil.

yourself or the machine.

Irom the work area.

TUEL TANK.

No smoking.

BEFUELLING

ae.org.u e.org.uk

For guidance on managing

construction health risks go to www.hse.gov.uk/construction

Using the Pressure Washer

Do not aim the water jet at yourself, any other persons, or any animals. It

Do not spray the water jet over any electrical equipment. This could cause

Do not connect or disconnect a pressure hose or lance while the washer

is pressurised. Stop the engine, and squeeze the lance trigger to release

7. Stop the engine and squeeze the lance trigger to release the pressure

8. If working in cold conditions, make sure that the water in the machine will

9. After work turn the detergent off or remove the detergent feed. Run the

11. Make sure that all the water filters are cleaned and properly protected

12. If the equipment does not work properly, do not attempt to repair it.

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

Fax: Email:

washer on just water to flush the detergent out. Then stop the engine, and

1. Wear protective equipment including goggles and waterproof overalls. 2. Hold the lance in both hands when squeezing the trigger because the water

a short circuit and fire. This could cause a fatal electric shock.

Stop the engine before leaving the machine unattended.

squeeze the lance trigger to release the pressure.

Hire Association Europe

ngham Business Park olihull B37 7YE

2450 Regents Court

The Crescent

RUN/STOP control.

handle off the shaft.

- pueu

the shaft easily.

that could get caught.

cold.

.6

.0

- 9

· 'G

.noiiisoq

from instruction 7 above.

ΛιμΟ

decompression lever.

Then start the engine again.

regarded as misuse by the hire

damage the engine and will be

Stop the engine using the stop control.

engine fires up, do not try to grab it.

smoothly the engine should fire up. If it doesn't, go through the steps again

iowering the decompression lever

broken if you wrap t around the

important. Your thumb could be

same side as your fingers - this is very

around the handle. Keep it on the

button, press it in when starting from

If the engine is fitted with a cold start

Move the decompression valve lever

also that the handle slides on and off

the ratchet mechanism works. Uneck

check by turning it anti-clockwise that

engine. Also, make sure that you have no loose clothing or flapping sleeves

Do not wear gloves when you start the

Check the throttle lever is in the IDLE

C. Fit the starting handle to the shaft, and

10. Grasp the starting handle firmly in one

into the decompression position.

prit do not wrap your thumb

11. Crank the engine strongly before

handle, and the engine kicks back.

14. Never stop the engine using the

13. If you let go of the handle when the

12. If the engine is now running, slide the

company.

nse the proper

siyT

ugl

10. Drain the machine if there is any danger, of overnight frost.

pressure will make it "kick back".

not start to freeze when not in use.

before you store the machine.

Contact the hire company.

will cause an injury.

the pressure.

when not in use.

3.

4

5

6.