



Using the Bumpa Hoist


1. Personal protective equipment must be worn at all times whilst operating the machine.
2. When connecting the electric motor to a 110v power supply a cable no longer than 10m should be used to avoid a voltage drop.
3. Check that the stop/power button is illuminated but not flashing, if the button is flashing then it indicates that one of the emergency stop buttons has been activated or the pendant control is not connected properly.
4. Adjust the loading guides at the base of the machine to ensure that the load goes up evenly.
5. When reversing the load will stop automatically on the stop gate at the base of the machine.
6. Do not improvise any replacement for worn or damaged parts. Only use replacements supplied by Mace Industries or the hire company.
7. Make sure nobody does anything to the machine that would affect its performance or is likely to damage it.
8. Do not use the machine to carry anything that is flammable or any materials that are hot and may set fire to or damage the hoist.
9. A competent person should check the connections at least once a week.
10. If the Bumpa hoist does not appear to be working properly, do not attempt to repair it. Contact the hire company.

Please keep this leaflet safely as it may be required for future reference

Electric Bumpa Hoist

Please read the entire leaflet before using the Bumpa hoist. There are rules and procedures that may require the person responsible for this equipment to carry out a specific risk assessment. This leaflet is not a substitute for a properly executed risk assessment.

1. This leaflet is intended as guidance on the safe erection and use of a Bumpa hoist.
2. A competent person must take responsibility for the safe use of the Bumpa hoist.
3. If you have not used this type of hoist before, familiarise yourself with how the Bumpa hoist works before you start loading the machine.
4. The Bumpa hoist is designed to provide a quick and safe way of transporting tiles, bricks, blocks and buckets from ground level to a roof, or similar high place, or from the roof to ground level.
5. Plan ahead to make sure that you are in a suitable environment to use the hoist.
6. The following items of personal protective equipment must be worn as a minimum – hard hat, safety boots and ear muffs or plugs giving protection up to 87dB(a).
7. The Bumpa hoist must not be used by minors or by anyone under the influence of drugs or alcohol.
8. The Bumpa hoist is designed for operation by an able bodied adult. Anyone with either a temporary or permanent disability must seek expert advice before using it.
9. The Bumpa hoist is a heavy machine, get help if you have to unload it from your vehicle. Do not lift beyond your own capabilities.



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
www.hae.org.uk

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE



1. If you are using a portable transformer, plug the transformer directly into the 230v socket. Do not use any 230v extension leads.
 2. Lay the extension cable out carefully, avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it, unroll it fully or it will overheat and could catch fire.
 3. Make sure that any extension cable connections are dry and safe.
- 110V ELECTRICAL SAFETY**
Your machine will only operate 110V. 110V machines will have a yellow industrial plug fitted.
1. The Bumpa hoist should be dismantled by reversing the erection procedure.
 2. The Bumpa hoist should be lowered gradually using the same rope method used to pull the machine up.
 3. Do not attempt to lower the machine until the motor has been stopped, is safe, and there is nothing on the belt.
- DISMANTLING THE BUMPA HOIST**
9. Finish erecting the machine by fixing the scaffold chute and pendant control to the end of the machine.
- Before Starting Work...**
2. Lock wheel brakes on, then with one individual standing on the hoop at the base of the machine to counterbalance the weight, a second individual raises the opposite end of the machine until the hoop reaches the floor.
 3. Release anti-tilt catches then walk out and rest the head of the machine on the top section until it makes an A shape
 4. Anyone working nearby should also wear appropriate PPE.
 5. Confirmation should be sought from the scaffold erector that the scaffold assembly is capable of supporting the Hoist, if there is any doubt then the scaffold erector should be present when the machine is being erected.
 6. Other persons working nearby must be given adequate protection from any suitable overhead protection from falling debris.
 7. The following items of personal protective equipment (PPE) are the minimum that should be worn whenever the equipment is used. Particular jobs or environments may require a higher level of protection. Ensure there is no loose or flapping clothing that could get caught in the machinery.
- BUMPA HOIST**
1. Inspect the Hoist and all equipment thoroughly. This should be carried out on first use and on a daily basis.
 2. If any problems are encountered with the Bumpa hoist or other hired equipment – do not use. Contact the hire company immediately.
 3. The machine should be serviced and tested least once a year by a competent person.
 4. Erecting the Bumpa Hoist
 5. First select a suitable level area to open the hoist. Always check for overhead obstructions prior to opening the hoist.
- RECTING THE BUMPA HOIST**
1. Only the 10 metre Bumpa hoist: To support the middle of the machine the prop extension should be put in place to stop the machine from bending in the centre.
 2. Lay the extension cable out carefully, avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it, unroll it fully or it will overheat and could catch fire.
 3. Make sure that any extension cable connections are dry and safe.



1. An appropriate person should assess the suitability of the products to be carried up on the Bumpa hoist. It must be able to safely carry cargo up either in the buckets or on the supports.
2. Do not use this machine where there is a danger of explosion. It may ignite fumes from petrol or gas cylinders.
3. If the Bumpa hoist is to be clamped to scaffold, the scaffold erector should be informed so that provision can be made for it.
4. Confirmation should be sought from the scaffold erector that the scaffold assembly is capable of supporting the Hoist, if there is any doubt then the scaffold erector should be present when the machine is being erected.
5. Other persons working nearby must be given adequate protection from any suitable overhead protection from falling debris.
6. The following items of personal protective equipment (PPE) are the minimum that should be worn whenever the equipment is used. Particular jobs or environments may require a higher level of protection. Ensure there is no loose or flapping clothing that could get caught in the machinery.